

Moisture meter

User manual LF-TD

Profinet


Humidity transmitter series



78.0°F | 6.16% | 456kg/m³ | -27.3td | 0.64aw | 51.9%r.H. | 14.8%abs | 100.4g/m² | 09m/s | 4.88M/hd

Overview of your LF-TD Profinet

Overview of the basic unit



No	Description
1	Humidity and temperature sensor
2	Sensor head
3	Sensor cable
4	Aluminum housing
5	Sensor Connector
6	RJ45 connector
7	Fastening tab

Table of Contents

Overview of your LF-TD Profinet	2
Overview Basic unit	2
1. Introduction	5
1.1 Information about this instruction manual	5
1.2 Limitation of Liability	5
1.3 Symbols used	6
1.4 Customer Service	6
2. For your safety	7
2.1 Intended use	7
2.2 Improper use	7
2.3 Qualification of the operator	7
2.4 General Security	8
2.5 Warranty	8
3. Get started	8
3.1 Unboxing the device	8
3.2 Check the scope of delivery	8
3.2.1 Scope of Delivery	9
4. Installation of the humidity temperature transmitter	9
4.1 Laying of the supply or transmission line	9
4.2 Sensor head mounting	10
4.3 Connector assignment	11
4.4 Wiring diagram	11
5. Integration into a B&R control system	12
5.1 GSD Package	12
5.2 Settings on the B&R Profinet Master	12
5.3 Settings on the B&R Profinet slave	14
5.4 Settings in the B&R software	16
5.5 Program code in ANSI C for integration	17
6. Technical drawing LF-TD Profinet	18
7. Alignment behavior of the sensor	18
8. Definition of humidity	19
8.1 Scope of use	19
9. Care and maintenance	20

9.1	Care instructions	20
9.2	Cleaning the device	20
10.	Verification of calibration	21
10.1	Assembly of the calibration device	21
10.2	Determining the Variance	22
11.	Disruptions	23
12.	Storage and disposal	24
12.1	Store the device	24
12.2	Disposing of the device	24
13.	Information about the device	25
13.1	CE Declaration of Conformity	25
13.2	Technical Data	27

1. Introduction

1.1 Information about this instruction manual

This instruction manual enables safe and efficient handling of the LF-TD Profinet. The operating instructions are part of the device and must be kept accessible to the operator in its immediate vicinity at all times.

The operator must have read and understood this instruction manual carefully before commencing any work. The basic prerequisite for safe working is compliance with all the safety instructions and instructions given in this operating manual.

1.2 Limitation of Liability

All information and information in this operating manual has been compiled taking into account the applicable standards and regulations, the state of the art and the many years of knowledge and experience of Schaller Messtechnik GmbH.

Schaller Messtechnik GmbH assumes no liability for damage in the following cases and the warranty claims expire:

- Failure to follow the instructions
- Unlawful use
- Insufficiently qualified operator
- unauthorized conversions
- Technical changes
- Use of non-approved spare parts

This rapid measurement method can be influenced by various boundary conditions.

As the manufacturer, we are not liable for any incorrect measurements and any consequential damage resulting from them.

1.3 Symbols used

Safety instructions are indicated by symbols in this user manual.



NOTE

Failure to do so can result in property damage.



Information

Identifies important information, the observance of which results in a more efficient and economical use.

1.4 Customer Service

For technical information, please contact our customer service:

Schaller Messtechnik GmbH
Max-Schaller-Straße 99
A - 8181 St.Ruprecht an der Raab



Phone: +43 (0)3178 28899
Fax: +43 (0)3178 28899 - 901

E-mail: info@humimeter.com
Internet: www.humimeter.com

© Schaller Messtechnik GmbH 2024



Information

Your purchased measuring device can be calibrated using suitable test ampoules / calibration ampoules and the adjustment can be checked. For this purpose, only use the calibration solutions sold by Schaller Messtechnik GmbH. For your test ampoules / calibration ampoules, you can download a calibration certificate under [https:// www.humimeter.com/certificates/](https://www.humimeter.com/certificates/) with the batch number printed on the ampoule.

2. For your safety

The device complies with the following European directives:

- Restriction of hazardous substances in electrical and electronic equipment (RoHS Directive)
- Electromagnetic compatibility (EMC Directive)

The device is built according to the latest state of the art. Nevertheless, there are residual dangers .

To avoid danger, you must follow the safety instructions.

2.1 Intended use

- Transmitter for the detection and transmission of relative humidity and temperature in fixed installations
- The sensor technology used makes it possible to detect even small fluctuations in humidity and their tendencies quickly and reliably and to carry out preventive actions.
- In some applications (e.g. duct installations) it is necessary to use a remote measuring probe for reasons of temperature adjustment.

2.2 Improper use

- The device must not be used in ATEX areas.

2.3 Qualification of the operator

Only persons who can be expected to carry out the work reliably are permitted to operate the device. Persons whose ability to react is affected, e.g. by drugs, alcohol or medication, are not admitted.

Persons using this device must have read and understood the user manual and follow its instructions.

2.4 General Security

Observe the following safety instructions to avoid personal injury and property damage :

- If you notice loose parts or damage to the device, contact your dealer.

Before your device is delivered, all technical characteristics have been checked and subjected to precise quality control. There is a serial number in each device. This sticker must not be removed.

2.5 Warranty

Excluded from the warranty:

- Damage caused by non-observance of the operating instructions
- Damage caused by third-party interventions
- Products that have been improperly used or altered without authorization
- Products where the warranty seal is missing or has been damaged
- Damage due to force majeure, natural disasters, etc.
- Damage due to improper cleaning

3. Get started

3.1 Unboxing the device

- Unpack the device.
- Immediately after unpacking, check the integrity and completeness of the device.

3.2 Check the scope of delivery

Check the list below to check the completeness of the delivery:

3.2.1 Scope of Delivery

- LF-TD Profinet
- Connection cable 1.9 m
- Optional

accessories:

- Display for LF-TD
- Display with keyboard for LF-TD
- Relay output for humidity
- Mounting bracket for LF-TD
- Sensor Cap Brass Sintered
- Drip Protection LF-TD Transmitter
- Stainless Steel Mesh Filter
- Special request flat rate for humidity transmitter series per order (regardless of quantity)
- Calibration certificates, calibration devices, humidity standards and reference devices - for ongoing monitoring


4. Installation of the humidity temperature transmitter

4.1 Laying of the supply or transmission line


- The line must not be laid in the area of interference fields.
- The transmitter must not be operated in the vicinity of electromagnetic interference fields.
- Permissible cross-sections for installation must be observed.
- The cable length must be kept as short as possible.
- » If the extension is necessary, the cross-section of the extension must ^{not be less than} 0.25 mm².
- When earthing the electronic housing and the display electronics, an appropriate equipotential bonding cable must be provided.

4.2 Sensor head mounting

- The measuring probe must be installed in a location that is representative for the measurement data recording.
 - » Avoid a position with draughts or unnatural temperature fluctuations.
 - » Furthermore, make sure that the device is not exposed to direct sunlight .
- Do not unscrew the probe cap!
 - » In the event of any twisting of the sensor head, tightness is no longer guaranteed.
- If there is a risk of condensation, mount the sensor tube vertically upwards.
- Mounting in an air duct (or at installation locations where there may be temperature differences between the sensor tube and the sensor housing):
 - » The remote sensor head must be completely located in the air duct or medium. If the sensor is only plugged into the air duct from the outside, there may be a temperature gradient along the sensor.
 - » Mount the sensor according to the sketch:



4.3 Connector assignment



Cable color	Pin No.	Function
Brown	1	Power Supply V- (0 VDC) Ground Current Output
White	2	Power supply V+ (12 to 29 VDC)
Blue	3	Current output humidity 4 - 20 mA
Black	4	n.c.
Grey	5	Current output temperature 4 - 20 mA
Violet	Case	Equipotential bonding GND




HINWEIS

Electronic damage due to incorrect cable connection

Falsche Belegungen können zu schweren Schäden an der Elektronik führen.

- Schließen Sie alle Kabel korrekt an.

4.4 Wiring diagram




5. Integration into a B&R control system

5.1 GSD Package


- The GSD package required for integration into a control system is provided to the customer by Schaller .
 - The GSD package is a zip file that contains the required GSD file as well as the instructions .
- » The integration was implemented with a B&R control system.

- The Profinet sensor is connected to the Profinet Master with a suitable Ethernet cable (Fig. 1).




5.2 Settings on the B&R Profinet Master


1. IP address of the master.



2. Station name of the sensor: "schaller-lftd2020".




3. The IP address of the sensor is assigned by the controller.




4. From the controller's point of view, 8 words (16BIT) are defined as inputs and 8 words (16BIT) as outputs.

» These settings must be identical on the master and on the sensor for communication to work.



5. Overview Address Table Profinet stations with "schaller-lftd2020".



5.3 Settings on the B&R Profinet slave

1. Overview profinet Sensor Schaller GmbH.

IO Device: LFTD2020_V2_4X Device ID: 0x0010
 Vendor: Schaller Messtechnik GmbH Vendor ID: 0x010C

Navigation Area

- Configuration
 - General
 - Modules
- Description
 - Device Info
 - Module Info
 - GSDML Viewer

General

Name of station: schaller-lftd2020

Description: LFTD2020_V2_4X

IP settings

IP address: 192.168.100.20

Network mask: 255.255.255.0

Gateway address: 0.0.0.0

Note: These values are set by the controller of the network!

2. 8 x Input Register (16BIT).

IO Device: LFTD2020_V2_4X Device ID: 0x0010
 Vendor: Schaller Messtechnik GmbH Vendor ID: 0x010C

Navigation Area

- Configuration
 - General
 - Modules
- Description
 - Device Info
 - Module Info
 - GSDML Viewer

Modules

	Slot	Sub Slot	Module
[-]	0	1	LFTD2020_V2_4X (LFTD2020_V2_4X)
		1	LFTD2020_V2_4X
		32768	Interface
		32769	Port 1
		32770	Port 2
[+]	1	1	ABP_UIINT16_WRITE
		1	ABP_UIINT16_WRITE
[+]	2	1	ABP_UIINT16_READ
		1	ABP_UIINT16_READ

Add Module Add Submodule Remove

Use of slots: 3/65

State of data length: Input 22/1440 Octets, Output 22/1440 Octets, In-Output 44/2880 Octets

Submodule details

Dataset: I/O data Display mode: Decimal

Direction	Consistence	Data type	Text ID	Length
INPUT	--	unsigned16	Humid	2
INPUT	--	unsigned16	Temp	2
INPUT	--	unsigned16	Status	2
INPUT	--	unsigned16	Counter(ms)	2
INPUT	--	unsigned16	SerialNr	2
INPUT	--	unsigned16	FWVersion	2
INPUT	--	unsigned16	M2HSerial	2
INPUT	--	unsigned16	ADI#1, Element#8	2

3. 8 x Output Register (16BIT).

IO Device: LFTD2020_V2_4X Device ID: 0x0010
 Vendor: Schaller Messtechnik GmbH Vendor ID: 0x010C

Navigation Area

- Configuration
 - General
 - Modules
 - Description
 - Device Info
 - Module Info
 - GSDML Viewer

Modules

Slot	Sub Slot	I	Module
0		1	LFTD2020_V2_4X [LFTD2020_V2_4X]
		1	LFTD2020_V2_4X
		32768	Interface
		32769	Port 1
		32770	Port 2
1		1	ABP_UINT16_WRITE
		1	ABP_UINT16_WRITE
2		1	ABP_UINT16_READ
		1	ABP_UINT16_READ

Use of slots: 3/65
 State of data length: Input 22/1440 Octets, Output 22/1440 Octets, In-Output 44/2880 Octets

Submodule details

Dataset: I/O data Display mode: Decimal

Direction	Consistence	Data type	Text ID	Length
OUTPUT	--	unsigned16	ADI#2, Element#1	2
OUTPUT	--	unsigned16	ADI#2, Element#2	2
OUTPUT	--	unsigned16	ADI#2, Element#3	2
OUTPUT	--	unsigned16	ADI#2, Element#4	2
OUTPUT	--	unsigned16	ADI#2, Element#5	2
OUTPUT	--	unsigned16	ADI#2, Element#6	2
OUTPUT	--	unsigned16	ADI#2, Element#7	2
OUTPUT	--	unsigned16	ADI#2, Element#8	2

4. Device information Anybus module Profinet.

IO Device: LFTD2020_V2_4X Device ID: 0x0010
 Vendor: Schaller Messtechnik GmbH Vendor ID: 0x010C

Navigation Area

- Configuration
 - General
 - Modules
 - Description
 - Device Info
 - Module Info
 - GSDML Viewer

Device Info

Name	Value
Main family	General
Product family	LFTD2020
DAP vendor name	Schaller Messtechnik GmbH
DAP hardware release	--
DAP software release	V2.40
Extendet address assignment	false
Physical slots	0..64
Max. IO data length	2880
Max. input data length	1440
Max. output data length	1440
Info text	Schaller Messtechnik GmbH

5.4 Settings in the B&R software

- The inputs and outputs are automatically created in the project and must now be assigned to the corresponding process variables.

Channel Name	Process Variable	Data Type	Task Class	Inverse	Simulate	Source File	Description [1]
ModuleCk	LFTD20_Online	BOOL	Automatic	<input type="checkbox"/>	<input type="checkbox"/>	\4PP065_0571_P...	Module status (1 = module present)
Module001_Humid	LFTD20_IN1	UINT	Automatic	<input type="checkbox"/>	<input type="checkbox"/>	\4PP065_0571_P...	ABP_UINT16_WRITE <Slot 1>
Module001_Temp	LFTD20_IN2	UINT	Automatic	<input type="checkbox"/>	<input type="checkbox"/>	\4PP065_0571_P...	ABP_UINT16_WRITE <Slot 1>
Module001_Status	LFTD20_IN3	UINT	Automatic	<input type="checkbox"/>	<input type="checkbox"/>	\4PP065_0571_P...	ABP_UINT16_WRITE <Slot 1>
Module001_Counter_ms	LFTD20_IN4	UINT	Automatic	<input type="checkbox"/>	<input type="checkbox"/>	\4PP065_0571_P...	ABP_UINT16_WRITE <Slot 1>
Module001_SerialNr	LFTD20_IN5	UINT	Automatic	<input type="checkbox"/>	<input type="checkbox"/>	\4PP065_0571_P...	ABP_UINT16_WRITE <Slot 1>
Module001_FWVersion	LFTD20_IN6	UINT	Automatic	<input type="checkbox"/>	<input type="checkbox"/>	\4PP065_0571_P...	ABP_UINT16_WRITE <Slot 1>
Module001_M2HSerial	LFTD20_IN7	UINT	Automatic	<input type="checkbox"/>	<input type="checkbox"/>	\4PP065_0571_P...	ABP_UINT16_WRITE <Slot 1>
Module001_ADI_1_Element_8	LFTD20_IN8	UINT	Automatic	<input type="checkbox"/>	<input type="checkbox"/>	\4PP065_0571_P...	ABP_UINT16_WRITE <Slot 1>
Module002_ADI_2_Element_1		UINT					ABP_UINT16_READ <Slot 2>
Module002_ADI_2_Element_2		UINT					ABP_UINT16_READ <Slot 2>
Module002_ADI_2_Element_3		UINT					ABP_UINT16_READ <Slot 2>
Module002_ADI_2_Element_4		UINT					ABP_UINT16_READ <Slot 2>
Module002_ADI_2_Element_5		UINT					ABP_UINT16_READ <Slot 2>
Module002_ADI_2_Element_6		UINT					ABP_UINT16_READ <Slot 2>
Module002_ADI_2_Element_7		UINT					ABP_UINT16_READ <Slot 2>
Module002_ADI_2_Element_8	LFTD20_CMD	UINT	Automatic	<input type="checkbox"/>	<input type="checkbox"/>	\4PP065_0571_P...	ABP_UINT16_READ <Slot 2>

- Process variables:

Name	Type	Constant	Retain	Value	Description [1]
LFTD20_Online	BOOL	<input type="checkbox"/>	<input type="checkbox"/>		
LFTD20_Humid	REAL	<input type="checkbox"/>	<input type="checkbox"/>		
LFTD20_Humid_INT	INT	<input type="checkbox"/>	<input type="checkbox"/>		
LFTD20_Temp	REAL	<input type="checkbox"/>	<input type="checkbox"/>		
LFTD20_Temp_INT	INT	<input type="checkbox"/>	<input type="checkbox"/>		
LFTD20_Cnt	UINT	<input type="checkbox"/>	<input type="checkbox"/>		
LFTD20_IN1	UINT	<input type="checkbox"/>	<input type="checkbox"/>		LFTD-AnybusCC[1] : Humidity
LFTD20_IN2	UINT	<input type="checkbox"/>	<input type="checkbox"/>		LFTD-AnybusCC[2] : Temperc
LFTD20_IN3	UINT	<input type="checkbox"/>	<input type="checkbox"/>		LFTD-AnybusCC[3] : Status
LFTD20_IN4	UINT	<input type="checkbox"/>	<input type="checkbox"/>		LFTD-AnybusCC[4] : Counter
LFTD20_IN5	UINT	<input type="checkbox"/>	<input type="checkbox"/>		LFTD-AnybusCC[5] : SerialNr
LFTD20_IN6	UINT	<input type="checkbox"/>	<input type="checkbox"/>		LFTD-AnybusCC[6]
LFTD20_IN7	UINT	<input type="checkbox"/>	<input type="checkbox"/>		LFTD-AnybusCC[7] : Version
LFTD20_IN8	UINT	<input type="checkbox"/>	<input type="checkbox"/>		LFTD-AnybusCC[8]
LFTD20_CMD	UINT	<input type="checkbox"/>	<input type="checkbox"/>		LFTD-AnybusCC[16] : Comma

5.5 Program code in ANSI C for integration

1. It is recommended to use the counter as a watchdog.
 - » The counter is incremented by the sensor every millisecond.
2. Thus, the function of the sensor can be monitored using the counter.
 - » If the counter does not change for a longer period of time, it is necessary to restart communication with the module.
3. With the LFTD Profinet (new) with display, the Profinet connection is cut when you leave the measurement window or the module is deactivated.
 - » In contrast to the LFTD-Profinet (old) with AnybusIC, the device starts the measurement automatically after start-up
4. With the variable "ModulOk" or "LFTD20_Online" in conjunction with the counter "LFTD20_Cnt", a reliable check of the function of the sensor and the communication can be realized.
 - » A measurement interval with the provision of the data takes less than a second.

```
#include <bur/plctypes.h>

#ifdef _DEFAULT_INCLUDES
#include <AsDefault.h>
#endif


void _INIT C_TestInit(void)
{
    LFTD20_CMD = 0;
    LFTD20_IN1 = 0;
    LFTD20_IN2 = 0;
    LFTD20_IN3 = 0;
    LFTD20_IN4 = 0;
    LFTD20_IN5 = 0;
    LFTD20_IN6 = 0;
    LFTD20_IN7 = 0;
    LFTD20_IN8 = 0;

    LFTD20_Online = 0;
    LFTD20_Humid_INT = 0;
    LFTD20_Humid = 0.0;
    LFTD20_Temp_INT = 0;
    LFTD20_Temp = 0.0;
}

void _CYCLIC C_TestCyclic( void )
{
    LFTD20_Humid = ((float)(INT)LFTD20_IN1/128.0);
    LFTD20_Temp = ((float)(INT)LFTD20_IN2/128.0);
    LFTD20_Cnt = LFTD20_IN4;

    if( (LFTD20_Online==0) && LFTD20_CMD ) {
        LFTD20_CMD = 0;
    }
}
```


6. Technical drawing LF-TD Profinet



7. Alignment behavior of the sensor

In humidity and temperature measurement, several parameters are responsible for the alignment behavior (time until the actual measured value is displayed). The parameter that can cause the largest measurement error is the temperature difference between the sensors or the entire measuring device and the material or air to be measured.

Therefore, let your device adjust until the displayed temperature corresponds to the actual temperature. In the following diagram you can see how long it takes to adjust from 20°C to 30°C.



To illustrate the importance of temperature equalization between the measuring instrument and the object to be measured, here is a table for the measurement error with a temperature difference between the measuring instrument and the object to be measured of 1 °C/1.8 °F at different ambient temperatures.

	10 °C (50 °F)	20 °C (68 °F)	30 °C (86 °F)
10 % RH	+/- 0,7 %	+/- 0,6 %	+/- 0,6 %
50 % RH	+/- 3,5 %	+/- 3,2 %	+/- 3,0 %
90 % RH	+/- 6,3 %	+/- 5,7 %	+/- 5,4 %

At room temperature (20 °C/68 °F) and an assumed humidity of 50 % relative humidity, a temperature deviation of 1 °C/1.8 °F between the sensor and the object to be measured results in an incorrect measurement of 3.2 % relative humidity. A deviation from

3 °C/5.4 °F would cause a measurement error of over 10 % relative humidity.

8. Definition of humidity


The relative humidity indicates the ratio between the instantaneous water vapour pressure and the maximum possible, the so-called saturation vapour pressure.

The relative humidity shows the degree to which the air is saturated with water vapour. Examples:

50% relative humidity: At the current temperature and pressure, half of the air is saturated with water vapour. At 100% humidity, it would be completely saturated. If the air has more than 100% humidity; the excess moisture would condense or precipitate as fog.

8.1 Scope of use

The device operates within the specified accuracy in the normal range. Long-term use outside the normal range of application (max. range), especially with humidity above 80%, can lead to higher measurement deviations. When returning to the normal application range, the sensor returns to the specified accuracy by itself.



9. Care and maintenance

Regular cleaning and maintenance ensure that your device remains intact for as long as possible.

9.1 Care instructions

- Do not leave the device in the rain.
- Do not submerge the sensor in water.
- Do not expose the device to extreme temperatures.
- Avoid strong mechanical vibrations or loads.

9.2 Cleaning the device



NOTE

Damage or destruction of the sensor

Contact with water or cleaning agents can destroy the sensor.

- ▶ Carry out dry cleaning only.

Aluminum housing and sensor head

Clean the aluminum housing and sensor head with a dry cloth.

Air Humidity and Temperature Sensor

It is not possible to clean the humidity and temperature sensor. In the event of soiling, contact your dealer.

10. Verification of calibration


Prerequisite: Calibration device (item no. 10006) and humidity standard (item no. 10005). The device, as well as the calibration device and the calibration solutions, must have a temperature between 20.0 °C and 26.0 °C. It is recommended to store the device, as well as the calibration device and calibration solutions, in a room with low temperature fluctuations for 24 hours.

10.1 Assembly of the calibration device

1. If necessary, place the sealing ring over the thread of the lower part as shown in Figure 2 .



2. Place the textile pad in the lower part (Fig. 3) and carefully pour the moisture standard onto the pad, starting with the humidity standard of 35% relative humidity.



3. Carefully place the upper part on the lower part (picture 4) and screw the upper part clockwise.

- » Recommendation: While screwing the upper part into place, leave the lower part on the table.
- » If necessary, lift the calibration device just straight up, do not tip or turn them over.



4. If lifted, carefully place the LF-TD Profinet with the calibration device on a flat table.
5. Slide the sensor head into the upper part (Figure 5).
 - » Make sure to lift the device with the calibration device only straight up and not to tip it over or turn it over. Otherwise, the sensor may be damaged.
 - » Leave the calibration device mounted on the sensor head until explicitly stated otherwise.



HINWEIS

Damage or destruction of the sensor

The sensor can be destroyed by tilting or turning the measuring device with the calibration device mounted.

- ▶ Achten Sie darauf, das Gerät nur gerade hochzuheben.

10.2 Determining the Variance

1. Allow the probe to adjust to the humidity standard for at least 2 hours.
2. Read the displayed humidity value and write it down together with the displayed temperature.
3. At ideal temperature conditions (measuring device, calibration device and calibration solution have 23 °C), the value printed on the humidity standard can be used as a reference value.
4. If there is a deviation from the factory temperature (23.0 °C), the real humidity value must first be determined according to the table below.

Temperature	Calibration Solutions		
	35 %	50 %	80 %
20 °C	34,6 %	49,8 %	79,9 %
21 °C	34,8 %	49,8 %	80,0 %
22 °C	34,9 %	49,9 %	80,0 %
23 °C	35,0 %	50,0 %	80,0 %
24 °C	35,1 %	50,1 %	80,0 %
25 °C	35,2 %	50,2 %	80,0 %
26 °C	35,4 %	50,2 %	80,1 %

5. Make a note of the real moisture value.
6. Compare the noted displayed value with the real moisture value.
 - » If the displayed value shows a deviation of less than 1.5 % relative humidity, it is recommended not to recalibrate.
 - » If the displayed value has a deviation of more than 1.5% relative humidity, contact your dealer in this case.
7. Now remove the calibration device from the sensor tube and repeat the work steps from point "[10.1 Installation of the calibration device](#)" either optionally with the humidity standard 50 % relative humidity or with the humidity standard 80 % relative humidity.

11. Disruptions

If the measures mentioned below do not remedy the faults or if other faults not listed here occur, please contact Schaller Messtechnik GmbH.

Disruption	Cause	Action
Incorrect measurement	Temperature out of range: below -20 °C or above +90 °C	Use the measuring device only for temperatures above -20 °C or below +90 °C.
	Measurement error due to too short temperature adjustment time	Allow the device to adjust to the environment for a sufficient amount of time (see "7.
	Heat or cold sources that do not correspond to the ambient temperature	Position your device in a new location that is representative of the indoor climate.
	Dripping water or sprayed water	Direct contact of the sensor with dripping water or sprayed water destroys the sensor.
	Irreversible impairment of the sensor element by aggressive gases	In this case, contact your dealer.
	Risk of condensation during temperature change	Condensation on the sensor will affect calibration . Allow the device to adjust to the ambient temperature.
	Dirty humidity sensor	In this case, contact your dealer.
	Foreign objects on the sensors	In this case, contact your dealer.

12. Storage and disposal

12.1 Store the device

Store your device under the following conditions:

- Do not store outdoors
- Store in a dry and dust-free place
- Protect from sunlight
- Avoid mechanical vibration/loads
- Storage temperature: -20 °C to +60 °C

12.2 Disposing of the device



The equipment marked with this symbol is subject to the European Directive 2012/19/EU of the European Parliament and of the Council of 4 July 2012 on waste electrical and electronic equipment.

If the device is not operated within the European Union, the national disposal regulations in the respective user country must be observed.

Electrical appliances do not belong in the household waste.

Dispose of the device in an environmentally friendly manner via suitable collection systems.

13. Information about the device

13.1 CE Declaration of Conformity

CE DECLARATION OF CONFORMITY DECLARATION OF CONFORMITY

Name/ Address of the manufacturer: **Schaller Messtechnik GmbH**

Name/ address of manufacturer: **Max-Schaller-Straße 99
A – 8181 St. Ruprecht**

Product name: **Schaller**

Product designation:

Type designation: **LF-TD-A ; LF-TD 60 ; LF-TD 90 ; LF-TD 120 ; LF-TD 150; LF-TD 180 ; LF-TD-E ; LF-TD-U ; LF-TD-ER ; LF-TD Profinet ; LF-TD-H**

Type designation:

Product Description: **Measuring device for determining the relative humidity and derived measurands**

Product description **Measuring instrument for determining relative humidity and derived measured variables**

The designated product complies with the provisions of the Directives:

The designated product is in conformity with the European directives:

EMC Directive 2014/30/EC

EMC Directive 2014/30/EU

RoHS - Directive 2011/65/EC

RoHS Directive 2011/65/EU

The conformity of the designated product with the provisions of the Directives is demonstrated by full compliance with the following standards:

Full compliance with the standards listed below proves the conformity of the designated product with the provisions of the above-mentioned EC Directives:

EN 61326-1:2013

Electrical Measuring, Control, Regulation and Laboratory Equipment - EMC Requirements
Electrical equipment for measurement, control, and laboratory use – EMC requirements

EN IEC 63000:2019-05
replaced

EN 50581:2012

Technical documentation for the assessment of electrical and electronic equipment with regard to the restriction of hazardous Fabrics.
Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances.


For the listed product, complete documentation with operating instructions is available in the original version.

For the mentioned product, a complete documentation with manual of instruction in original version is available.

In the event of changes not specified by the manufacturer, this declaration of conformity loses its validity.

In case of any changes not agreed upon with the manufacturer, this declaration of conformity loses its validity.

St. Ruprecht a.d. Raab, 31.07.2022





Schaller
Messtechnik / Humfmetec.com
Schaller Messtechnik GmbH
Maunz - Schaller Straße 99
AT - 8150 St. Ruprecht a. Raab
www.humfmetec.com | info@humfmetec.com

Bernhard Maunz
Legally binding signature of the issuer
Legal binding signature of the issuer

13.2 Technical data

Measuring range of relative humidity	0% to 100%
Calibration of relative humidity	10% to 90%
Accuracy of relative humidity	+/- 2.0 % (at 25 °C)
Measuring range temperature	-20 °C to +90 °C
Calibration Temperature	+10 °C to +60 °C
Accuracy Temperature	+/- 0.3 °C (at 25 °C) / +/- 0.5 °F (at 77 °F)
Operating Temperature	-20 °C to +90 °C (sensor head) -20 °C to +85 °C (electronics)
Outputs	Relative humidity (4 - 20 mA) -Scaling (0% to 100%) Temperature (4 - 20 mA) -Scaling (-20 °C to +90 °C) Load < 500 Ohms (UB 24 V)
Temperature compensation	Automatic
Power supply	12 to 29 VDC
Current consumption	18 mA (without output, display or any bus systems)
Electrical connection	Sensor connector with 1.9 m cable
Dimensions housing	70 x 32 x 120 mm
Material housing	Anodized aluminum
Sensor head dimensions	12 x 125 mm
Sensor head material	Stainless steel
Sensor cap	Stainless steel sintered
Degree of protection for electronic housings	IP 54



Gewerbehau Ergolz, Wölferstrasse 5

4414 Füllinsdorf

Phone: +41 (0)55 617 00 80

Fax: +41 (0)55 617 00 81

www.grubatec.ch

sales@grubatec.ch