
6. Wood types

Wood type	Sub categories	Measuring range limit
Beech	Rubber, Eucalyptus	47 %
Oak	Mahogany, Wenge	47 %
Alder	Acacia, Alstonia, Birch, European chestnut, Horse chestnut, Cherry Tree, Walnut, Okan	54 %
Ash	Keruing	54 %
Spruce		67 %
Pine	Balsa, Yew Tree, Stone Pine	54 %
Larch	Maple, Douglas Fir, Hemlock, Poplar, Elm	47 %
Fir	Ceiba, Lime	59 %
Willow	Pear, Hickory, Olive wood, Ramin, Teak	59 %
Test block	! Only for testing the moisture meter !	

Explanations to wood types and sub categories:

The wood types listed in the "Wood type" column are displayed in the measurement window of the humimeter . If you want to measure a type of wood that is not displayed on the device, search for it in the subgroups and set the corresponding wood type on the device, e.g. if you measure poplar, set the wood type larch on the device.